

# 9360-10 INSTALLATION INSTRUCTIONS

STEP 1:  
SET I-BEAMS 10 FOOT APART ON CENTER.

STEP 2:  
MOUNT BOTTOM Z-BRACKETS A MINIMUM OF 8' ABOVE GROUND LEVEL.  
WELD OR BOLT BRACKETS TO I-BEAMS A MINIMUM OF 8'-1/4" FROM THE TOP OF THE I-BEAM (IF NO AD/SPONSOR PANEL).

STEP 3: LIFT SCOREBOARD, USING PROPER RIGGING, INTO BOTTOM Z-BRACKET AND SECURE WITH A TEMPORARY CLAMP.

STEP 4: BOLT OR WELD TOP Z-BRACKETS TO HOLD SCOREBOARD INTO PLACE.

## DETAIL A

