

# **EVERSAN**

[www.eversan.com](http://www.eversan.com)

## **MODEL 9342AFP**



## **PROFESSIONAL WORKOUT TIMER**

### **Instruction Manual**

**Address:** 34 Main Street, Whitesboro, NY 13492

**Phone:** 315-736-3967 • **Toll Free:** 800-383-6060 • **Fax:** 315-736-4058

**SCOREBOARDS • TIMERS • MESSAGE SIGNS • VIDEO DISPLAYS • WIRELESS**

# Table of Contents

Option List .....	1
Operating Instructions.....	2
Model 812V Battery Operation (optional).....	3



Page 1

**MODEL 9342AFP  
PROFESSIONAL WORKOUT TIMER  
INSTRUCTIONS**

These instructions must be followed to ensure correct operation. The warranty will be violated and considered null if inspection and operating procedures are disregarded.

Should you require assistance or have any questions, please call 1-800-383-6060.

The Eversan, Inc. scoreboard is a microprocessor-controlled device requiring very low power, fewer than 3 amps at 12V DC (Battery Operation) or standard 110VAC.

**OPTIONS FOR THE MODEL 9342AFP:**

- A. 12 Volt Battery Operation
- B. 220 volt AC power (Foreign)
- C. Cabled Remote Control Console (Optional)
- D. Wireless Operation

**Customer Shipping Inspection**

- A. Unpack the timer (save boxes)
- B. Unpack control cable and console, if ordered. (save boxes)

**NOTE:**

Prior to use, the timer should be tested for shipping damage as follows:

1. Stand the board upright and plug the console cable and console into the console connector on the timer, if required.
2. Connect the 30 Watt self-contained siren by plugging the two pin connector into the upper left side of the display and using the six 6-32 screws to secure the siren to the top of the unit.
3. Plug the power cord into a 120 VAC standard outlet.
4. If the board is working correctly the digits will go through a diagnostic by showing 8 and then going blank.

**See Operating Instructions to determine functions**

**NOTE:**

If there is any malfunction or shipping damage, notify the shipper and Eversan, Inc. Immediately.



## OPERATING INSTRUCTIONS

The Model 9342AFP Workout Timer allows you to set 1-9 periods with 1-9 intervals in each period. The timer also allows you to set the play clock from 0-99 seconds and reset it at any time.

**Power –up sequence for wireless system:** To ensure proper radio link with this 2.4GHz wireless display you must follow proper turn on procedures. First turn on the display, be sure antenna is attached. After the display goes through its check out, each digit shows an 8 and then goes blank, turn on the control console. The control console display will show; Wireless Network System ID= 54, or any 2-digit number, for 4 seconds; then Eversan, Inc. Scoreboards for 3 seconds; and the console display will show P=1 TIME=00:00 I=0, DELAY OF GAME=00. The timer display will show one zero in the delay of game time and two zero's in the seconds, the minutes will be blank along with the tens digit of the delay of game timer.

### Setting the Display

**DELAY OF GAME:** The delay clock is programmed and runs independently of the workout timer. To set the delay clock, press and release **DELAY OF GAME SET**, and enter a number 1-99 using the 0-9 keypad. Pushing and releasing the DELAY OF GAME SET button and then pushing the 2 and then the 5 using the keypad would set for example 25 seconds. To start the delay clock, press and release the **DELAY OF GAME RESET**. Every time you push and release the DELAY OF GAME RESET the delay clock will reset and begin to count down from the time set after pushing DELAY OF GAME SET.

**WORKOUT TIMER:** The workout timer is set by using the three buttons; PERIOD, INTERVAL, and TIME SET, and the 0-9 keypad. Using the functions provided you are able to set up your entire practice prior to stepping onto the field, but they also allow you to change on the go. After the initial checkout P=1 on the control console display. The INTERVAL can then be set from 1-9 by pressing and releasing the INTERVAL button and entering 0-9 on the keypad. The TIME SET button is used along with the keypad to set the length of time for each interval, pressing and releasing TIME SET and entering 0,2,3,0, using the keypad would set each interval at 2 minutes, 30 seconds. To set the time and the interval for period two press and release the PERIOD button and the console display will show P=2. Press and release the INTERVAL button and use the keypad set the amount of intervals, up to 9, required for period 2. Using the TIME SET and the keypad set the time for each interval. You continue in this sequence until all required periods, up to a maximum of 9, have been programmed. To start the workout press and release the STOP\GO button, green button on the 0-9 keypad.

**STOP\GO:** This button allows you to start and stop the workout if required. Pressing and releasing the button once will start the timer a second time will stop the timer.

**UPDATING WORKOUT:** The timer can always be updated to add flexibility to your workouts. To change the amount of periods, intervals in a period, or the time of an interval in any period is very simple. While the timer is running you still have the capability to modify the settings. For example if in period one you set the interval to 6 and decided after 4 intervals that you want 8 intervals press the interval button and press 4 on the keypad, I=4 will show on the console display and the workout will continue from there. You can be running period 1 and setting period 2.

## **Battery Operation: (12-volt DC) Optional:**

1. Attach Eversan's special battery connector to the 4-pin connector on the side of the scoreboard or control console.
2. Connect the cigarette lighter plug into the Eversan battery pack or a car cigarette lighter.

## **Charging**

The Battery should be charged after each use. Insert the cigarette lighter type plug of the charger into the receptacle on the side of the battery pack. Plug the charger into any standard 120volt household plug. Depending on the amount of drain on the battery, the following is a guide for recharging time. A 25% discharge requires 4 hours recharging. A 50% discharge requires 8 hours. A 100% discharge requires 14 hours recharging time.

### **NOTE:**

The Battery should NOT be left in the Recharging mode for more than 24 hours as this can damage the cell.

### **CAUTION:**

DO NOT attempt to charge this battery pack on currents other than 60-cycles 110volt/120volt AC current. Do not attempt to use the battery during charging.

## **Care of Battery Pack**

Under no circumstances should the battery pack be punctured or disassembled in any way. NEVER insert anything into the battery receptacle except a standard cigarette lighter type plug. The battery pack should always be stored in a fully charged condition and in a cool, dry place. When stored for a long period of time, the battery should be charged before use.



[www.eversan.com](http://www.eversan.com)

**MODEL9342AFP  
ALL SPORT  
INTERVAL TIMER**

**Address:** 34 Main Street, Whitesboro, NY 13492

**Phone:** 315-736-3967 • **Toll Free:** 800-383-6060 • **Fax:** 315-736-4058

**SCOREBOARDS • TIMERS • MESSAGE SIGNS • VIDEO DISPLAYS • WIRELESS**