

9875 TYPICAL INSTALLATION


STEP 1:
SET I-BEAMS 10 FOOT APART ON CENTER.

STEP 2:
ASSEMBLE 9875 PER ASSEMBLY INSTRUCTIONS, USING PROPER RIGGING LIFT. 9875 INTO PLACE, CHECK LEVEL AND SECURE USING 1/2" THREADED ROD, NUTS, WASHERS AND BRACKET SUPPLIED. A MINIMUM OF 8-BRACKETS SHOULD BE USED TO HOLD THE 9875 IN PLACE.

STEP 3: SCOREBOARD IS READY FOR WIRING.

BRACKET TO BE TIGHTENED TO THE BEAM USING NUT AND LOCK WASHER TO HOLD SCOREBOARD (ALL HARDWARE SUPPLIED)

1/2" THREADED ROD TO BE SCREWED INTO THE BACK OF THE SCOREBOARD



<p>REVISED BY: AR DATE: 5/15</p> <p>UNREVISIONED TOLERANCES:</p> <p>0.125 ± 0.005</p> <p>0.250 ± 0.010</p> <p>0.375 ± 0.015</p> <p>0.500 ± 0.020</p> <p>0.625 ± 0.025</p> <p>0.750 ± 0.030</p> <p>0.875 ± 0.035</p> <p>1.000 ± 0.040</p> <p>1.125 ± 0.045</p> <p>1.250 ± 0.050</p> <p>1.375 ± 0.055</p> <p>1.500 ± 0.060</p> <p>1.625 ± 0.065</p> <p>1.750 ± 0.070</p> <p>1.875 ± 0.075</p> <p>2.000 ± 0.080</p> <p>2.125 ± 0.085</p> <p>2.250 ± 0.090</p> <p>2.375 ± 0.095</p> <p>2.500 ± 0.100</p> <p>2.625 ± 0.105</p> <p>2.750 ± 0.110</p> <p>2.875 ± 0.115</p> <p>3.000 ± 0.120</p> <p>3.125 ± 0.125</p> <p>3.250 ± 0.130</p> <p>3.375 ± 0.135</p> <p>3.500 ± 0.140</p> <p>3.625 ± 0.145</p> <p>3.750 ± 0.150</p> <p>3.875 ± 0.155</p> <p>4.000 ± 0.160</p> <p>4.125 ± 0.165</p> <p>4.250 ± 0.170</p> <p>4.375 ± 0.175</p> <p>4.500 ± 0.180</p> <p>4.625 ± 0.185</p> <p>4.750 ± 0.190</p> <p>4.875 ± 0.195</p> <p>5.000 ± 0.200</p>	<p>EVERSAN</p> <p>TYPICAL 9875 INSTALL</p> <p>BEAM: W10 X 22</p> <p>MAX HT: 20' ABOVE GRD</p> <p>9875 INSTALL</p> <p>REV 1 OF 1</p>
--	--